

ALSAN FOAM CL-F

TECHNICAL DATA SHEET 200701SCANE

(supersedes -)

DESCRIPTION

ALSAN FOAM CL-F is a multi-purpose cleaning agent used to dissolve uncured or fresh polyurethane foam. Alsan Foam CL-F has been developed for cleaning foam guns, tools and work surfaces.

APPLICATION

Shake well the can containing ALSAN FOAM CL-F before using. For general cleaning purposes, insert the black spray activator onto the valve stem of the can. Press the black activator to spray ALSAN FOAM CL-F to the surface to be cleaned.

For foam gun unit cleaning: clean the gun adapter valve area using the general cleaning method written above to remove any fresh foam. Screw the can tightly onto the gun adaptor and press the trigger to flush ALSAN FOAM CL-F through the gun adapter for at least 5 seconds, ensuring it is thoroughly cleaned. For a multiple foam can project it is not necessary to flush the dispensing unit after every can; if switching to a new can of foam, always replace the empty product container immediately.

Read manufacturer's gun instructions for a perfect usage of the application tool.

RESTRICTION(S)

Hardened foam can only be mechanically removed. ALSAN FOAM CL-F contains active ingredients can dissolve and soften; plastics, paints, coatings, inks, labels, textiles etc... It is advisable to check the compatibility before cleaning.

FOR COMPLETE INFORMATION ON PRODUCT INSTALLATION, PLEASE CONTACT SOPREMA OR RESISTO

PACKAGING

Specifications	ALSAN FOAM CL-F
Physical state	Liquid
Chemical Base	Solvent-based Solvent-based
Colour	Clear

STORAGE AND HANDLING

24 months from date of production if stored in undamaged original and unopened packaging. Store in dry conditions and protected from direct sunlight at temperatures between $+5^{\circ}$ C and $+25^{\circ}$ C.

For more information and advice on the safe handling, storage and disposal of the chemical products, users shall refer to the most recent Safety Data Sheet (SDS) containing physical, ecological, toxicological and other safety related data.







SOPREMA.US • 1.800.356.3521

SOPREMA.CA • 1.877.MAMMOUTH